

# BRUSHED FINISH SOLID BRASS FREESTANDING PEDESTAL CYLINDRICAL SINK INSTALLATION INSTRUCTIONS



## PRIOR TO INSTALLATION

Please read installation instructions below. All plumbing should be installed in accordance with applicable building codes and regulations.

Unpack and inspect the items for any shipping damages. If you find damages, do not install.

All products must be installed by a professional and certified plumber otherwise warranty may be voided.

## POSSIBLE TOOLS REQUIRED\*



Plumbers Tape



Tape Measure



Level



Adjustable Wrench



Hex Wrench



Thread Sealant



Drill



Pencil or Marker



Screwdriver

\*not included

### 1. Verify Sink Location

Using a pencil mark the location where you want the sink to be onto the floor.

### 2. Connect Pipes

- Install waste and overflow into sink basin.
- Screw plumbing pipes into basin.

**NOTE:** Plumbing not included.

1 1/2" Discharge pipe location varies between models and may need to be re-plumbed before installation.

### 3. Connecting Plumbing

- We recommend installing the faucet (not included) of your choice while back of sink is accessible.
- Align pipes in basin to plumbing in wall.
- Tighten into place, with clockwise motion.

**NOTE:** Water shutoff valve should be slightly above the 1 1/2" drain line coming out of the wall.

### 4. Dry Fit Sink

Dry fit pedestal sink before final installation. Once you are ready for final installation, move on to step 5 below.

### 5. Seal Sink - 2 People Required

- Person 1- Slightly tilts sink back, so basin just barely lifts off ground.
- Person 2- Apply construction adhesive underneath the sink.
- Gently lower basin back to standing position.
- Caulk the sink to the floor with silicone or sealant of your choice.

**NOTE:** Do not use sink until 24 hours after sealing.

