

LENOX CHROME FINISH SINGLE HANDLE BATHROOM SINK FAUCET INSTALLATION INSTRUCTIONS




BEFORE YOU BEGIN

Before you begin, please read the installation instructions below. Observe all local building and safety codes.

Unpack and inspect the items for any shipping damages. If you find damages, do not install.

Please note all products must be installed by a professional and certified plumber otherwise warranty might be voided.

POSSIBLE TOOLS REQUIRED*



*not included





Technical Information

INSTALLATION: Single-Hole

MOUNT: Deck Mount

APERTURE: 1.18in / 30mm

FEATURES: Honeycomb nozzle

MATERIAL: Brass

SPOUT TYPE: Low Arc


SPOUT HEAD FUNCTION: Stream

NUMBER OF HANDLES: Single Handle


HANDLE TYPE: lever


CARTRIDGE TYPE: Ceramic Disk MAXIMUM FLOW RATE: 1.2 gpm


Faucet Size



Faucet Deck Mount Installation













BathSelect

Installation Instructions




1. Remove the mounting nut, metal washer, and rubber washer from the threaded pipe. Fit the O-ring into the groove of the faucet body. Screw waterlines into the corresponding screw-hole of the faucet body.

Step 3:




3. Connect waterlines to angle stops. Turn on the angle stops and check for leaks (DO NOT TURN FAUCET ON).

Step 2:



2. Insert waterlines and threaded pipe into the hole of the sink. Install rubber washer, metal washer, and mounting nut back to the threaded pipe. Adjust the faucet body correctly and secure with mounting screws tightly.

Step 4:




4. Turn faucet on for 1 minute to flush any debris.




Flexible Connecting Hose

Care must be taken when connecting the flexible connection hose from the power supply box to the spout to ensure it does not bend sharply and kink or twist. See Below for recommended ways to fit the flexible connecting hose.

Important: Failure to follow these guidelines may result in poor performance and damage to the flexible connection hose.








Care & Cleaning

- 1. The product can be cleaned with warm water, a mild soap and a clean soft cloth.
- 2. Clean progressively and gently.
- 3. It is not required to use any abrasive cleaning pads, wire wool or micro-fibre cloths to clean the product.
- 4. Avoid a vigorous cleaning action, as this could contribute to denaturing and dulling the finish.
- 5. Abrasive or strong cleaning products containing ammonia, bleaches, alcohol, dyes, acids (hydrochloric, formic, phosphorus, chlorine or acetic) will be detrimental to the product finish.

6. If using a spray cleaner, apply the cleaning agent onto a soft cloth, never directly spray onto the product as the cleaner may enter gaps and openings and cause damage. Do not allow the cleaner to remain on the product for a period of time. After cleaning, rinse thoroughly with clean water.







For more details, visit the product page:

