

20" Milan Recessed Stainless Steel Round Color Changing LED Rain Shower Head



BEFORE YOU BEGIN

Before you begin, please read the installation instructions below. Observe all local building and safety codes.

Unpack and inspect the items for any shipping damages. If you find damages, do not install.

Please note all products must be installed by a professional and certified plumber otherwise warranty might be voided.

POSSIBLE TOOLS REQUIRED*



Plumbers Tape



Tape Measure



Level



Adjustable Wrench



Hex Wrench



Thread Sealant



Drill




Pencil or Marker




Screwdriver

*not included

Step 1:




Step 2:





All dimensions and specifications are nominal and may vary. Use actual products for accuracy in critical situations.


Step 3:





Step 4:



Step 5:




Step 6&7:



Step 7:


13




Fix the shower head to the plate with the appropriate screws, using the special adaptor (S) for correct tightening.

Step 8:

14



Step 9:



MAINTENANCE:

Care and Cleaning of Chrome and Special Finishes (Fontana Showers Products)

To maintain the appearance and longevity of your Fontana Showers products, please adhere to the following guidelines:

DO NOT use steel wool or cleaning agents containing alcohol, acid, abrasives, or similar substances, as these may damage the surface finish.

For routine cleaning, use only soap and water, followed by drying with a clean cloth or towel. When cleaning bathroom tiles, ensure that your Fontana Showers product is protected from splashes or exposure to harsh cleansers.

Disassembling the Soap Pipe from the Pump

For Fontana Showers soap dispensers, the soap pipe can be detached from the pump using a simple slide-and-pull mechanism:

Locate the sliding ring of the quick-connection fixation nipple on the pump.

Pull the sliding ring downward to release the open end of the soap pipe.

Once released, the soap pipe can be easily removed.

Filter Cleaning Instructions (Foam Dispensers Only)

Fontana Showers foam dispensers are equipped with a foam filter. For optimal performance, it is recommended to clean the filter every six (6) months.

If soap flow decreases, the issue may be caused by a clogged filter. Follow these steps to clean or replace it:

Use a wrench to unscrew the quick-connection fitting from the foam compressor and remove the filter housing.

Take out the filter from the housing.

Replace the filter (recommended) or rinse it thoroughly under running water for a temporary solution.

Reassemble all parts securely.

By following these maintenance steps, you can ensure the reliable performance and durability of your Fontana Showers products.